

# **gizDuino miniUSB**

## **How to install USBasp driver to PC? If you are using gizDuino miniUSB?**

In order to use gizDuino USB mini, we need to install the USBasp driver. If there is no USBasp driver installed to your computer, a pop-up note will appear indicating "Found new hardware USBasp".

Download driver: <http://e-gizmo.net/oc/kits%20documents/GIZDUINO%20FOLDER/Drivers.zip>

1st Option:

1. Connect the gizDuino mini USB to PC.
2. Open Device Manager>Search the USBasp. (if there's a caution image- it means the driver is not installed properly or not detected.)
3. Right Click in USBasp>Update Drivers>Search automatically for updated driver software.
4. If nothing happens, select Browse my computer for driver software>locate the "usbasp-windriver.2011-05-28.", then wait until Driver installation successful. Done!

Unique solution ID: #1016

Author: Roma Mercado

Last update: 2018-04-18 10:55